

BARREL USER ADVICE

COMMISSIONING & MAINTENANCE OF BARRELS




1

Fill the barrel with approx.
5 Gal. of hot (around 104F)
filtered, chlorine-free water.



2

Roll the barrel. Turn the
barrel to wash both heads.
The water must touch all
internal surfaces.



3

Leave on each head for
one hour.



4

Remove bung and drain.



If a leak appears, fill the barrel full of water and leave until the leak is plugged.

Caution: Do not leave the barrel full of water for longer than 24h. Empty the barrel and rinse with fresh water before leaving to drain.

PROLONGED STORAGE OF NEW BARRELS



1

Leave the barrels with
their **protective plastic**
covering.



2

Store barrels in an
environment conforming to
the following specifications



Humidity:
around 75-85%



No air currents



Low light



Cover exposed parts to
protect against UV



As a general rule, to maintain barrel quality, **we recommend storing empty barrels in a cool, humid environment, away from sunlight and contact with air.**